

### Interior Signage Installation

Issued: May 4, 2020





since 1971

#### SIGNAGE GUIDELINES

DESIGN + WAYFINDING INTERIOR

### Room Identification

•	ADA Location Requirements	3-5
•	ADA Height Requirements	6-9
•	Puck System Mounting	10
-	Perpendicular Mount	11

### Individual Letters

•	Vinyl Installation	12
•	Tape Mount Installation	13
	Stud Mount Installation	14

### Overhead Signage

	Suspended Ceiling	15
-	Solid Ceiling	16
	Ceiling Frame	17

### **Directory Cabinet**

<ul> <li>Cleat Mount</li> </ul>	18	3
---------------------------------	----	---



### ROOM IDENTIFICATION: ADA LOCATION REQUIREMENTS



since 1971

SIGNAGE GUIDELINES


DESIGN + WAYFINDING
INTERIOR

### Character Height

Minimum character height for ceiling or projecting wall mounted directional or informational signage is 2", provided that the sign is mounted no more than 10' high from the floor or ground surface.

5/8" minimum character height for all signs mounted between 40" and 70" from the floor or ground surface. This applies to all identification, informational, and directional signs. The 5/8" minimum does not apply to such regulatory signs as EMTALA, patients rights & responsibilities, marketing notices, etc. For specific instances, always contact the ADA hotline for clarification prior to manufacturing.

No sign shall be mounted lower than 40" from the floor or ground surface.





### ROOM IDENTIFICATION: ADA LOCATION REQUIREMENTS




since 1971


#### SIGNAGE GUIDELINES

DESIGN + WAYFINDING INTERIOR

Tactile Sign Mounting
Tactile signs are to be mounted on
the latch side of the door, 2" from
the door frame, 48" minimum,
60" maximum measured to the
baseline of the raised characters.
Ideally, but not a requirement,
braille should be placed at one
consistent height whenever possible.



18" of clear free space (CFS) must be maintained at the sign location.





# ROOM IDENTIFICATION: ADA LOCATION REQUIREMENTS



since 1971

#### SIGNAGE GUIDELINES

DESIGN + WAYFINDING INTERIOR



Ideal Location on Latch Side of Door



Located on Push Side of Door if Door Opens Inward and Does Not have a Hold-open Device



Inset door opening, then Nearest Adjacent Wall



Inset door opening, No space on Latch Side



Double doors with 2 Active Leafs



Double Doors with 1 Active Leaf






since 1971

#### SIGNAGE GUIDELINES

DESIGN + WAYFINDING INTERIOR








since 1971

#### SIGNAGE GUIDELINES

DESIGN + WAYFINDING INTERIOR








since 1971

#### SIGNAGE GUIDELINES

DESIGN + WAYFINDING INTERIOR








since 1971

#### SIGNAGE GUIDELINES

DESIGN + WAYFINDING INTERIOR






# ROOM IDENTIFICATION: PUCK SYSTEM MOUNTING




since 1971


#### SIGNAGE GUIDELINES

DESIGN + WAYFINDING INTERIOR



Front View








# ROOM/PLACE IDENTIFICATION: PERPENDICULAR MOUNT





since 1971

#### SIGNAGE GUIDELINES

DESIGN + WAYFINDING INTERIOR









Double-Sided
Perpendicular Mount
Mounted to Wall Surface



#### **DIRECTING PEOPLE BY DESIGN**

### **INDIVIDUAL LETTERS:** VINYL INSTALLATION



since 1971

#### SIGNAGE GUIDELINES

DESIGN + WAYFINDING **INTERIOR** 


Step 1. Measure and layout prespaced vinyl lettering

Measure Twice!

Step 2 Tape lettering in place by making a "hinge" on the top.



Step 3 Lift letter set up to remove the backing paper. This leaves the letters on the masking tape.



Step 4 Begin to lay the lettering in place gradually. Squeegee it in place pushing out bubbles as you go. Go Slow!



and hinge from the glass leaving the vinyl lettering.













#### **DIRECTING PEOPLE BY DESIGN**

### **INDIVIDUAL LETTERS:** TAPE MOUNT INSTALLATION



since 1971

#### SIGNAGE GUIDELINES


DESIGN + WAYFINDING **INTERIOR** 



High Bond Vinyl Tape with Paper Backing on Back of Letters -Peel Paper off Prior to Installation



Paper Template and Taped Letters Provided by Innerface



Area. Pull Paper Pattern out from Behind Dimensionals and Press Letters Firmly to Wall. (Repeat as Necessary)





### **DIRECTING PEOPLE BY DESIGN**


# INDIVIDUAL LETTERS: STUD MOUNT INSTALLATION




since 1971

#### SIGNAGE GUIDELINES

DESIGN + WAYFINDING INTERIOR







Fill Holes with Silicone Adhesive and, Insert Studs into Drilled Holes. Pull Paper Pattern out from Behind Dimensionals.




### OVERHEAD SIGNAGE: SUSPENDED CEILING




since 1971


#### SIGNAGE GUIDELINES

DESIGN + WAYFINDING INTERIOR




### SUSPENDED CEILING DETAIL





SOLID CEILING DETAIL



**ELEVATION DETAIL** 




# OVERHEAD SIGNAGE: SOLID CEILING




since 1971

#### SIGNAGE GUIDELINES

DESIGN + WAYFINDING INTERIOR





ELEVATION DETAIL




# OVERHEAD SIGNAGE: CEILING FRAME




since 1971

#### SIGNAGE GUIDELINES

DESIGN + WAYFINDING INTERIOR








### **DIRECTORY CABINET: CLEAT MOUNT**





since 1971

#### SIGNAGE GUIDELINES

DESIGN + WAYFINDING **INTERIOR** 



















#### **DIRECTING PEOPLE BY DESIGN**